

GENERAL REQUIREMENTS

The stricter of 29 CFR 1926 and the Abbott Accident Prevention Plan



2024 Safety Declaration

Safety and accident prevention must be a part of the bid preparation when choosing to work with Abbott Construction. When bids are presented, it is understood that the submitting company will meet regulatory and Abbott standards for safety and accident prevention on all Abbott projects, as outlined in this Safety Declaration and more thoroughly specified in the Abbott Accident Preventaion Plan. When an Abbott requirement and a federal, state, or local requirement differ, the more stringent requirement will apply.

Trade Partner Pre-Mobilization

Prior to mobilization, each trade partner's project management and field supervisors will attend a pre-mobilization meeting led by the Abbott project team. Trade partner field supervisors will discuss detailed project-specific safety hazards and describe how they and their lower-tier subcontractors intend to implement and conform to the Abbott Accident Prevention Plan.

Daily All-Hands Production/Safety Huddle

As led by the Abbott project team at the beginning of each shift, all trade partner employees and lower-tier trade partner employees will participate in warm-up/stretching exercises, a meaningful discussion of planned work activities, and a critical review of each trade partner's pre-task plan.

Trade Partner Supervision and Safety Inspection and Oversight Requirements

Each trade partner and lower-tier subcontractor supervisor should have OSHA 30-hour training. Each trade partner will provide an on-site, full-time safety professional when the trade partner and its lower-tier trade partners collectively have 50 or more employees on site, unless the trade partner is working under a Corrective Action Plan, where a full-time safety professional may be required for fewer on-site employees. Trade partner supervisors will complete documented weekly safety audits in the Construct PM mobile app. These audits will describe the corrective actions taken for hazardous or non-compliant issues found.

Crew Pre-Task Planning

Prior to beginning its work tasks, each trade partner work crew supervisor will engage in a meaningful pre-task planning meeting. Each planning meeting must be an open discussion between the supervisor and the workers accountable to the supervisor, completed in the work area when possible. Supervisors must analyze tasks to be performed and identify the work sequence, hazards, training, controls, tools, and emergency action plans necessary to protect the workers. Tasks, especially high-hazard tasks, must be described, and the means to implement each task's hazard control methods must be communicated. Supervisors must ensure that workers understand the hazards and hazard control expectations beyond the use of PPE. At least daily, each supervisor must submit in the Construct PM mobile app the crew's completed pre-task plan.



Maximum Lifting Weight for Workers

No lift shall exceed 75 pounds unless a lift plan is approved by the Abbott project team.

Weekly Trade Partner Coordination Meeting

Each trade partner supervisor will attend a weekly planning, coordination, and safety meeting led by the Abbott project team.

Disciplinary Action

Trade partner and lower-tier subcontractor workers who fail to abide by the requirements of the Abbott Accident Prevention Plan may be suspended or removed from the site. This is intended to preserve safety-conscious working conditions for all workers and encourage each employee to be responsible and conscientious.

Housekeeping

Each trade partner will practice good housekeeping. Each trade partner will remove trash and debris during and after each shift. Cords and hoses will be elevated, bridged, buried, or controlled to eliminate trip hazards and reduce damage from equipment travel. Work areas will be kept organized and free from clutter. Walkways and stairs will be kept clear.

Equipment Operation

Equipment operators must show proof of training. All equipment must be operated and maintained in strict accordance with the manufacturers' written instructions.

Incident Reporting

All incidents (injuries, illnesses, property damage, close calls) will be reported immediately to the Abbott project team, regardless of the actual or potential consequences. On a case-by-case basis, as determined by the Abbott project team, post-incident drug testing may be required for anyone involved in an incident involving injury or property damage.

Personal Protective Equipment

Unless the task requires a higher level of personal protection, at a minimum, clear eye protection conforming to ANSI/ISEA Z87.1, hard hats conforming to ANSI/ISEA Z89.1, high-visibility apparel conforming to ANSI/ISEA 107 Class 2, and gloves conforming to ANSI/ISEA 105 Cut Level A4 will always be worn on the site outside of an office setting or an enclosed cab. Protective footwear conforming to ASTM F2413 will be worn at all times on the site.

Fall Protection

Each trade partner will abide strictly by Abbott's safe work practices when working from heights. When exposed to a fall of six feet or more, fall protection must be used. When engineering controls do not eliminate the fall hazard, 100% tie-off is required using a full-body harness fully compliant with 29 CFR 1926 Subpart M. Shock absorbing lanyards are prohibited; self-retracting deceleration devices (yoyos) are recommended.

| Signature CEO/Principal | Date | |
|-------------------------|------|--|
| Company | Name | |





